

Product information - Instructions- Manual

Art. 8725.05 Melting plate

Date last modified: 5-8-2022, Changes reserved for printing- and typing errors.

Product image



Product information

The melting plate is a heated plate to level poured candles in a simple manner. The plate is provided with notches to drain the excess melted candle wax. This is collected by a collecting tray, which can be placed under the plate.

There is also a useful melting support, which is optional (8725.06). This can set the candles at right angles during the melting. The support can be adjusted to different positions with three knobs, so that most candle shapes can be flattened horizontally.

Installation

- 1. Always place the melting plate on a stable surface.
- Connect the device to an earthed socket with 230 Volt.
- Switching on the device is done by inserting the plug into the socket. Switching off is done by removing the plug from the socket again.
- 4. The melting plate is ready for use.

Use of appliance

- 1. Place a container under the appliance.
- Optional: adjust the melting support to the desired position to melt horizontally.
- 3. Switch on the device by inserting the plug into the

socket.

- Wait until the plate is completely heated through.
- Place the bottom of the candle that has to be melted on the plate when the plate is fully heated. Melt the bottom of the candle with a rotating movement. Make sure the candle is held horizontally.
- Optional: regularly press the candle against the melting support to melt the candle horizontally.
- After use, switch off the appliance by removing the plug from the socket.

Note!

The melting plate needs time to heat up (approx. 1/2 hour). The block can get hot, but it won't get extremely hot. Take this into consideration. Never use the melting plate for improper use. This is to prevent damage and increase the lifespan. Improper use also invalidates the warranty.

Cleaning

- 1. Make sure the plug is out of the socket.
- 2. The plate is easy to clean with kitchen paper while it is still warm. Use this paper to clean the top and the notches until all the paraffin remains have been removed.
- Attention! Never bring the device into contact with water.
 After this, the device is ready for
- use again.

Specifications

Plate length	250mm
Plate width	200mm
Wattage	90Watt
Voltage	230Volt
Maximum protection	✓

Warranty

The melting plate comes with a oneyear warranty against material and construction defects, provided that the device has been used and maintained in accordance with the instructions. Also, the melting chain must not be mishandled or abused in any way. This only applies to parts, not to labor and transport. In the event of malfunctions, please contact your supplier in order to have the malfunction resolved with the original parts.

Warning: as this involves heating a liquid, operation of the melting tank should only be done by qualified personnel.

The device complies with EU directives 73/23 EEC and 89/336 EEC, all technical changes reserved.

CE



Elektrisch schema

