

Product information - Instructions- Manual

# Art. 9106 Mould Cleaner SP30-SP60

Date last modified: 5-8-2022, Changes reserved for printing- and typing errors.

### Product image



#### **Product information**

The mould cleaner type SP30-SP60 is an isolated heating cabinet and is suitable for cleaning and preheating molds.

The cabinet is made of stainless steel material. The temperature is easy to set by means of the thermostat (30- $95^{\circ}$ C).

## Installation

- 1. Always place the heating cabinet on a stable surface.
- 2. Connect the device to an earthed socket with 230 Volt.
- 3. The heating cabinet is ready for use.

#### Use of appliance

- Place kitchen paper on the removable bottom of the cupboard (absorption function). Make sure it does not come into contact with the heating element.
- Place the dirty moulds, upside down, on the fitted kitchen paper.
- 3. Switch on the temperature between 60 and 90°C.
- 4. Attention! Depending on which moulds are placed, the temperature setting must be taken into account. Not every type of mould is resistant to long heating! There is a difference between moulds made of polycarbonate and moulds made of plastic.
- 5. In time, all moulds will be clean

and ready to use!

- 6. Turn off the thermostat and remove the moulds from the cabinet.
- Remove the 'dirty' kitchen paper. If necessary, clean the cabinet with kitchen/cleaning paper (not with water)!

NB! The heating element and the inside of the cabinet become warm/hot during use.

#### Use of appliance preheating

- Place the clean and prepared moulds (with wick) on the rack.
- 2. Switch on the temperature between 60 and 90°C.
- 3. Attention! Depending on which moulds are placed, the temperature setting must be taken into account. Not every type of mould is resistant to overheating! There is a difference between moulds made of polycarbonate and moulds made of plastic.
- 4. In time, all moulds will be sufficiently preheated and ready to use!
- 5. Turn off the thermostat and remove the moulds from the cabinet.
- 6. The moulds are now ready to be filled.

Preheated moulds give the candles a smoother appearance.

#### Note!

Never use the heating cabinet for improper use. This is to prevent damage and increase the lifespan. Improper use also invalidates the warranty.

#### Cleaning

- 1. Make sure the plug is out of the socket.
- 2. Clean the cabinet with a piece of kitchen or polishing paper. This works best when the cabinet has just been switched off and is therefore still warm. NB! The

element may still be hot.

 If necessary, the device can still be cleaned with a hot damp cloth.

### Specifications

Height type SP30	545mm
Height type SP60	850mm
Width	450mm
Depth	450mm
Wattage type SP30	400Watt
Wattage type SP60	1000Watt
Voltage	230Volt
Thermostat setting	30-90°C

#### Warranty

The mould cleaner comes with a oneyear warranty against material and construction defects, provided that the device has been used and maintained in accordance with the instructions. Also, the melting chain must not be mishandled or abused in any way. This only applies to parts, not to labor and transport. In the event of malfunctions, please contact your supplier in order to have the malfunction resolved with the original parts.



2: Door 3: Door handle 4: Thermostat + knob 5: On/Off switch 6: Plug + cord 7: Intermediate shelf

The device complies with EU directives 73/23 EEC and 89/336 EEC, all technical changes reserved.



Always read the manual before using the device

SELLACOHOLLAND Morseweg 1 8503 AH JOURE T+31(0)513-499657 E info@sellacq-holland.nl

www.sellacq-holland.nl

## Electric scheme

